

General Tedlar® Cleanability & Stain Removal Information

Table 1
Stain Removal Tests for Vinyl Wall Covering Clad with *Tedlar*® SP PVF Film

| Staining Agent* | Dry Cloth | Wet Cloth | Spray Cleaner | 91% Propanol | MEK |
|-----------------------|-----------|-----------|---------------|--------------|-----|
| Worcestershire Sauce | S | R | | | |
| Black Crayon | | | R | | |
| Brown Shoe Polish | S | S | R | | |
| Chocolate Syrup | S | R | | | |
| Lipstick | S | S | R | | |
| Calamine Lotion | S | R | | | |
| Tea | | R | | | |
| Iodine | S | R | | | |
| Mercurochrome | | S | R | | |
| Catsup | | S | R | | |
| Grape Juice | S | R | | | |
| Spray Paint | | | | S | R |
| Brake Fluid | S | R | | | |
| Mustard | S | R | | | |
| Red Wine | | R | | | |
| Asphalt | | | R | | |
| Coffee | S | R | | | |
| Betadine | S | R | | | |
| Sodium Hydroxide | R | | | | |
| 30% Sulfuric Acid | R | | | | |
| 20% Hydrochloric Acid | R | | | | |
| 10% Nitric Acid | R | | | | |
| Methyl Ethyl Ketone | R | | | | |
| Gasoline | R | | | | |
| Toluene | R | | | | |
| Acetone | R | | | | |
| Glacial Acetic Acid | R | | | | |
| 10% Citric Acid | R | | | | |
| Ethylene Glycol | R | | | | |
| Ethyl Alcohol | R | | | | |

*Staining agents were allowed to set 24 hours prior to cleaning.
S = Left Slight Shadow After Cleaning
R = Stain Completely Removed